

# Butting a Corner Joint



1. Attach the molded FauxPanels™ corner to the wall by applying glue to the backside of the corner and screwing it into the wall using drywall screws.



2. Next, align a FauxPanels™ standard panel (or trim an interlock panel) to the molded corner.



3. Use caulking to hide the gap.



4. Continue as explained in [Basic Instructions](#).

**MAKE SURE** to observe and obey all safety rules and recommendations set forth by tool manufacturers and local, state, and federal authorities for any building project including all applicable building codes.