

# Using Molded Corners



1. Panel the walls with Faux Panels™ or siding as explained in [Basic Instructions](#).



2. Next, attach the molded Faux Panels™ corner to the wall directly on top of the paneling by applying glue to the backside of the corner and screwing it into the paneling using drywall screws.



3. For a final finish, use Faux Panels™ color-matched caulk to fill all of the screw holes and any gaps, even wide gaps. Smooth the caulk and wipe away any excess. A wet rag works well for this.

**MAKE SURE** to observe and obey all safety rules and recommendations set forth by tool manufacturers and local, state, and federal authorities for any building project including all applicable building codes.