

Installing Windsor Window/Door Trim



1. Attaching Accessories

- Windsor Faux Panels™ are designed to work with accessory pieces.
- Accessory pieces make the job go smoother with professional results.
- With accessories, there are no exposed edges and no caulking required.



2. Door Trim Attachment

- Use a level when locating Door Trim.
- Measure Total height of the wall before the ledger attachment.



3. Mitering the Trim Piece

- Cut the top of the piece on a 15 degree angle, with the long side of the angle against the wall



4. Attach the Trim Piece

- Toe Screw the piece through the top and down along the inside edge, making sure to attach securely to the underlying substrate.



5. The Final Look

MAKE SURE to observe and obey all safety rules and recommendations set forth by tool manufacturers and local, state, and federal authorities for any building project including all applicable building codes.